

## 【INSTALLATION GUIDE】

<p>Step 1: Mark the mounting holes on the bottom board of the cabinet as shown.</p>	<p>Step 2: Fix the slides on the bottom board of the cabinet with screws.</p>
<p>Step 3: Assemble the connecting rod with the upper and bottom basket with M6 nuts.</p>	<p>Step 4: Fix the assembled organizer on the slides.</p>