

【INSTALLATION GUIDE】

1. Put the elevator into the cabinet, make the left and right sides of the control box close to the inner side wall of the cabinet, and the bottom of the control box overlaps with the cabinet floor;
2. Adjust the distance between the front side of the control box (A in the figure below) and the outer side of the cabinet (B in the figure below) to 70mm. One person holds the control box and the other pulls down the storage shelf.
3. First use a ST4*14 wood screw to screw into one of the 5 small holes on the control box (C in the figure below) and tighten it, and then tighten the remaining 4 wood screws.
4. Install the control box on the other side in the same way.
5. There is no need to remove the protective film to install the product, and it is removed when used by the end customer.

Note: If there is abnormal noise during use, please add a small amount of lubricating oil to the corresponding rotating position.

